

Dual Mode Bluetooth Wireless Ergonomic Backlit Mechanical Gaming Keyboard 87 KEYS Blue Switch

MODEL NUMBER: SANOXY-KEYBOARD4



Highlights

- SANOXY Mechanical Keyboard 87 Keys White LED Backlight Gaming Keyboard, Wired/Wireless BT Keyboard Gaming/Office for iOS Android Windows MacOS and Linux (Blue Switch-Black) Supports wireless BT and USB wired dual mode connection. Supports NKRO in wired mode, and 16 keys without conflict in wireless mode. 87 key compact layout, backlit, and with 8 kinds backlit displaying modes for option. Press Fn+ScrLK to switch to. Power saving, for MacOS and Windows: This keyboard is Compatible with most operating systems, including Windows XP/Vista/7/8/10, iOS, macOS, Linux, and Android.

Features

Supports 2.4GHz wireless and USB wired dual mode connection. Supports NKRO in wired mode, and 16 keys without conflict in wireless mode. 87 key compact layout, saves more room on your desktop. Pure white backlit, and with 8 kinds backlit displaying modes for option. Press Fn+ScrLK to switch to. Power saving, the backlit automatically turns off after 1min inactivity, keyboard turns into sleep mode after 3mins no operation. Blue Switch: Tactile and clicky with a bump feel. It is suitable for typing. Blue switch is louder than other mechanical switches when typing. Wireless & Wired Dual Mode White Backlit Mechanical Gaming Keyboard BT connection method Reminder: BT pairing is required for the first use of BT mode, wired / BT mode switching method: FN + P indicator flashes to indicate successful switching . Pairing method: 1. Make sure that it is currently in BT mode (judgment method: Fn + Q, indicator flashes-BT mode; indicator does not flash-wired mode) 2. BT pairing: press and hold Hold down the P key while holding down Fn, release it when the P key flashes, and add (search) a BT keyboard pairing connection named RK bluebooth keyboard on the computer. After successful pairing, the P key stops flashing 3. Multi-group BT pairing method, in the first step, Fn + Q / W / E can be used to pair three groups of BT devices.

Note: Please contact Sanoxy sales team at sales@sanoxy.com for buying options & available models for bulk purchases.

<https://www.sanoxy.com>